

Revit Architecture 2013 Keyboard Shortcuts.

Applications Menu		View>Windows		Zoom	
Ctrl+N	New	WC	Cascade Windows	ZA	Zoom All to Fit
Ctrl+O	Open	WT	Tile Windows	ZE/ZF/ZX	Zoom to Fit
Ctrl+S	Save	KS	Keyboard Shortcuts	ZO/ZV	Zoom Out(2x)
Ctrl+P	Plot	KS	Keyboard Shortcuts	ZP/ZC	Previous Pan/Zoom
Architecture>Build		Manage>Settings		ZR/ZZ	Zoom in Region
WA	Wall	UN	Project Units	ZS	Zoom Sheet Size
DR	Door	Modify>Clipboard		Shift+W	Steering Wheel
WN	Window	MA	Match Type Properties	Snaps	
CM	Place a Component	Modify>Geometry		PC	Snap to Point Clouds
CL	Column	CP	Cope; Apply Notching	SC	Centres
Architecture>Room & Area		PT	Paint	SE	Endpoints
RM	Room	RC	Cope: Remove Notching	SI	Intersections
RT	Tag Room	SF	Split Face	SM	Midpoints
Architecture>Datum		Modify>Modify		SN	Nearest
LL	Level	AL	Align	SO	Snap Off
GR	Grid	AR	Array	SP	Perpendicular
Architecture>Work Plane		CO/ CC	Copy	SQ	Quadrants
RP	Reference Plane	CS	Create Similar	SR	Snap to Remote Objects
Annotate>Dimension		DE	Delete	ST	Tangents
DI	Aligned Dimension	DM	Mirror - Draw Axis	SW	Work Plane Grid
EL	Spot Elevation	MM	Mirror - Pick Axis	SX	Points
Annotate>Text		MV	Move	SZ	Close
TX	Text	OF	Offset	Function Keys	
FR	Find/Replace	PN	Pin	F1	Displays Revit Help
Annotate>Tag		RE	Scale	F7	Spelling
TG	Tag by Category	RO	Rotate	F8	Navigation Wheel
Collaborate>Synchronize		SL	Split Element	F9	Spelling
RL	Reload Latest	TR	Trim/Extend to Corner	F10/Alt	Keytips
ER	Editing Requests	Up	Unpin		
View>Graphics		Modify>Geometry			
VG/VV	Visibility/Graphics	EH	Hide in View: Hide Elements		
TL	Thin Lines	EOD	Override Graphics in View		
RR	Render	LW	Linework		
RC	Render in Cloud	SF	Split Face		
RG	Render Gallery	VH	Hide in View: Hide Category		
		Modify>Properties			
		PP	Properties		
Spacebar	Can be used to flip selected elements or rotate 90 degree each time the spacebar is pressed.				
Tab	Cycles through different snaps while creating walls and line, placing components, or moving or pasting elements.				